



STRIKEMASTER® LITHIUM 24v BATTERY CHARGING BASE QUICK START




IMAGE 1

FOR USE WITH STRIKEMASTER®
4AH BATTERY(LTV-B) ONLY.

1. Remove 24v Battery Charging Base from carton (Image 1).
2. Unpack Battery Charging base and plug it in. Slide Battery onto Battery Charging Base using the channels on both sides as a guide. Press down until you hear it click in place. Leave Battery on Battery Charging Base until fully charged (Image 2).
NOTE: Battery is not fully charged when first removed from box.

3. When Battery Charging Base indicator shows solid green, your Battery is fully charged (Image 3). Your StrikeMaster Lithium 24v Battery is ready for use.

Your StrikeMaster Lithium 24v Battery Charging Base has built in "Smart Charging Technology". The chart below shows you the correct charging procedure/occurrences that could be experienced while charging.

4. Your Battery must be charged in a location where the temperature is more than 35°F/2°C, but less than 100°F/38°C.



IMAGE 2



IMAGE 3

CHARGING PROCEDURE

BATTERY IS CHARGING

GREEN (BLINKING)



FULLY CHARGED

GREEN



BATTERY IS TOO COOL OR
TOO WARM TO CHARGE
(REFER TO OWNERS MANUAL)

RED



DEFECTIVE BATTERY
(REFER TO OWNERS MANUAL)

RED (BLINKING)



REGISTER YOUR PRODUCT ONLINE TO ACTIVATE YOUR WARRANTY

www.strikemaster.com/warranty